


# trunki®

Making travel child's play



## Folding Seat


Instruction Booklet

---

Read all instructions before assembly and use of chair. Keep instructions for future use.

# Parts List

**DE** Teileliste. **FR** Liste des pièces. **ES** Lista de piezas. **IT** Elenco delle parti. **NL** Onderdelenlijst. **PL** Lista części. **CZ** Seznam dílů.



## EN

- A** Harness strap
- B** Cross strap
- C** Tray
- D** Tray release lever
- E** Leg attachment strap  
(for opening and folding)
- F** Anti-slip feet  
(front and rear)
- G** Release buttons  
(for opening and folding)
- H** Strap adjuster
- I** Back support
- J** Rear mounting strap

## IT

- A** Cinghia dell'imbracatura
- B** Cinghia trasversale
- C** Vassoio
- D** Leva di sgancio del vassoio
- E** Cinghia di fissaggio per le gambe
- F** Piedini antiscivolo  
(anteriori e posteriori)
- G** Pulsanti di sgancio  
(per aprire e chiudere)
- H** Regolatore della cinghia
- I** Supporto per la schiena
- J** Cinghia di montaggio posteriore

## DE

- A** Gurtsystem
- B** Kreuzgurt
- C** Tablett
- D** Tablett-Entriegelungshebel
- E** Beingurt
- F** Anti-Rutsch-FüÙe  
(vorne und hinten)
- G** Entriegelungsknöpfe  
(zum Öffnen und Zusammenklappen)
- H** Gurtversteller
- I** Rückenstütze
- J** Hinterer Befestigungsgurt

## NL

- A** Harnasriem
- B** Kruisriem
- C** Legblad
- D** Ontgrendelingshendel voor legblad
- E** Beenbevestigingsriem
- F** Antislipvoetjes  
(voor en achter)
- G** Ontgrendelknoppen  
(voor openen en opvouwen)
- H** Bandversteller
- I** Rugsteun
- J** Bevestigingsriem aan de achterkant

## FR

- A** Sangle de harnais
- B** Sangle transversale
- C** Plateau
- D** Levier de déverrouillage du plateau
- E** Sangle de fixation pour les jambes
- F** Pieds antidérapants  
(avant et arrière)
- G** Boutons de déverrouillage  
(pour l'ouverture et le pliage)
- H** Réglage de la sangle
- I** Support dorsal
- J** Sangle de fixation arrière

## PL

- A** Pasek uprzęży
- B** Pasek poprzeczny
- C** Tacka
- D** Dźwignia zwalniająca tackę
- E** Pasek mocujący nogę
- F** Nóżki antypoślizgowe  
(przód i tył)
- G** Przyciski zwalniające  
(do otwierania i składania)
- H** Regulator paska
- I** Podparcie pleców
- J** Tylny pasek montażowy


## ES

- A** Correa del arnés
- B** Correa cruzada
- C** Bandeja
- D** Palanca de liberación de la bandeja
- E** Correa de sujeción para las piernas
- F** Patas antideslizantes  
(delanteras y traseras)
- G** Botones de liberación  
(para abrir y plegar)
- H** Ajustador de correa
- I** Respaldo
- J** Correa de montaje trasera


# How to install.

**DE** Wie installiert man. **FR** Comment installer. **ES** Cómo instalar. **IT** Come installare. **NL** Hoe installeren. **PL** Jak zainstalować.


01




02




03




04




05




06




07




08




09




10



11






12



# How to Disassemble

**DE** Wie zerlegt man. **FR** Comment démonter. **ES** Cómo desmontar. **IT** Come smontare. **NL** Hoe demonteren. **PL** Jak zdemontować.



**trunki**®

Making travel child's play


SAFETY STANDARD EN 16120-2012+A2-2016+AC-2018  
 SUITABLE FROM: 6 MONTHS - 3 YEARS OR 15KG  
 IMPORTANT! ADULT ASSEMBLY REQUIRED! PLEASE READ THIS MANUAL  
 CAREFULLY AND KEEP IT FOR REFERENCE!  
 DIMENSIONS OPEN: 41X 40 X 48CM  
 DIMENSIONS FOLDED: 41 X 40 X 14CM

## WARNING !

NEVER LEAVE YOUR CHILD UNATTENDED! DO NOT USE THIS PRODUCT ON STOOLS OR BENCHES.  
 ALWAYS USE THE RESTRAINT SYSTEM AND ENSURE IT IS CORRECTLY FITTED!  
 ALWAYS USE THE CHAIR ATTACHMENT SYSTEM AND ENSURE IT IS CORRECTLY FITTED BEFORE USE!  
 ALWAYS CHECK THE SECURITY AND THE STABILITY OF THE PRODUCT ON THE ADULT CHAIR BEFORE USE!  
 DO NOT USE THE CHAIR MOUNTED SEAT IF ANY PART IS BROKEN, TORN OR MISSING!



1. Please read this manual carefully and keep them for future reference. Failure to follow the instructions can affect your child's safety.
2. Do not use this product on stools or benches.
3. This product is intended for children able to sit unaided (minimum 6 months) and up to 36 months (3 years) or up to a maximum weight of 15 kg.
4. Position the adult chair with the chair mounted seat placed in a position where the child is not able to use its feet to push against the table or any other structure as this can cause the adult chair supporting the chair mounted seat to tip over.
5. Do not use the chair mounted seat if any part is broken, torn or missing.
6. Do not use any replacement parts or accessories other than those approved by or supplied by Apramo.
7. Always use the restraint system and the chair attachment system.
8. NEVER use in or near water: Do not use in water or as a bath seat.
9. Do not place or position the seat near any item which could present a danger of suffocation, strangulation, e.g. strings, blind/curtain cords, etc or falling objects.
10. Do not transport the seat with baby in.
11. Only attach to chairs with 4 legs.
12. Never use on swivel chairs or chairs with wheels, stools, folding chairs or other surfaces that are not stable.
13. Do not place the device on a table or other raised area. Don't use it on a sofa or as a car seat.
14. Only attach to a chair with a backrest with a minimum height of 50 cm and a minimum width of 29 cm. Also with a minimum seat width of 42 cm and a minimum depth of 40 cm as shown in the diagram below.



## WARNING !

### Using as a floor chair

- NEVER use in or near water or as a bath seat.
- STOP using [on the floor] when child can climb out or walk - more likely to be accidents on the floor level because an older child is able to tip the seat over by pushing against the floor with its feet.
- Strangulation risk: When using as a floor chair ensure that the rear mounted strap is tucked away in the seat cover and the leg attachment strap is removed and stored in a safe place.

## CARELESSNESS CAUSES FIRE

### Cleaning

Wipe all plastic parts with a warm damp cloth and a mild nonabrasive detergent.

- Light soiling of the seat can be removed with a warm damp cloth using a detergent.
- NEVER use any strong detergents or abrasive materials to clean your dining chair.
- Ensure all parts are completely dry before using.

## INSTRUCTIONS

### Open dining chair

1. First, push both Release Buttons (G) all the way in to release the Tray (C).
2. The Tray (C) will automatically rise slightly.
3. Fully open the legs and lift the Back support (I) upwards 2.  
Now lift the Tray (C) upwards 3 until you hear a "click" and it locks in place.
4. Push the front corners of the seat down until you hear a "click" as they lock in place.

### Securing the dining chair

5. Centre the booster seat on a stable chair and do not go over the edge of the chair.
6. To level the booster seat, rotate the Anti-slip Feet (F) on the base before attaching the Leg Attachment Straps (E).
7. Attach the Leg Attachment Strap (E) to one side of the booster seat, pass it under the chair and then re-attach it to the opposite side of the booster seat.
8. Tighten the Leg Attachment Strap (E) on both sides of the booster seat to ensure a secure fit.
9. Open the Rear Mounting Strap (J), loop it around the back of the chair, fasten the buckle and tighten the strap.
10. Open the belt buckles, place the child on the booster seat, preferably with the Tray (C) removed (see the "Removing and fitting the tray" section below), then fully tighten the Harness Straps (A).

### Removing and fitting the tray

11. Remove the Tray (C) by pressing the two Tray Release Levers (D) on the bottom of the Tray (C) and lifting upwards off the dining chair.
12. Reverse this process until you hear a "click" to put the Tray (C) back on to the dining chair.

### Folding the dining chair

13. Lift the seat up until it locks out of position.
14. Fully depress both Release Buttons (G) and push the Tray (C) down. Close the legs and the Back support (I) 2 together and fold the Tray (C) down until you hear a "click" 3.

**©Heroes Group 2024**  
Trunki is a Heroes Group trade mark.  
Onco Group Limited  
Wisteria Grange Barn, Pikes End, Pinner,  
Middlesex, HA5 2EX, UK.  
EU Representative:  
Heroes Iberia, S.L.U.  
Calle del Limonero, 22,  
28020 Madrid, Spain.  
[compliance@makeheroes.co](mailto:compliance@makeheroes.co)

